

## Two Year Limited Warranty

(Valid in USA only)

HoMedics, Inc., guarantees this product free from defects in material and workmanship for a period of two years from the date of original purchase, except as noted below.

This HoMedics product warranty does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product; or any other conditions whatsoever that are beyond the control of HoMedics. This warranty is effective only if the product is purchased and operated in the USA. A product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications is not covered under warranty. HoMedics shall not be responsible for any type of incidental, consequential or special damages. All implied warranties, including but not limited to those implied warranties of fitness and merchantability, are limited in the total duration of two years from the original purchase date.

To obtain warranty service on your HoMedics product, either hand deliver or mail the unit and your dated sales receipt (as proof of purchase), postpaid, along with check or money order in the amount of \$10.00 payable to HoMedics, Inc. to cover handling.

Upon receipt, HoMedics will repair or replace, as appropriate, your product and return it to you, postpaid. If it is appropriate to replace your product, HoMedics will replace the product with the same product or a comparable product at HoMedics' option. Warranty is solely through HoMedics Service Center. Service of this product by anyone other than HoMedics Service Center voids warranty.

This warranty provides you with specific legal rights. You may have additional rights which may vary from state to state. Because of individual state regulations, some of the above limitations and exclusions may not apply to you.

For more information regarding our product line in the USA, please visit: [www.homedics.com](http://www.homedics.com)

# BubbleBliss™ Elite

## Luxury Foot Bubbler



### Instruction Manual and Warranty Information

BB-5

#### Mail To:

**HoMedics  
Consumer Relations  
Service Center Dept. 168  
3000 Pontiac Trail  
Commerce Township MI  
48390**

#### Email:

[cservice@homedics.com](mailto:cservice@homedics.com)

Treat your feet to bubbling relief.

Thank you for purchasing Bubble Bliss Elite, HoMedics luxury foot bubbler. This, like all HoMedics products, is built with high-quality craftsmanship. Bubble Bliss Elite is guaranteed to provide you with soothing massage for years to come.

HoMedics is dedicated to bringing you better health through innovation. However, you should never substitute this, or any other manufacturer's product, for professional medical attention. Persistent ailments and symptoms could indicate a more serious condition.

**Caution:**  
All servicing of this footbath must be performed by authorized HoMedics service personnel only.

## **IMPORTANT SAFETY INSTRUCTIONS:** **WHEN USING ELECTRICAL PRODUCTS, ESPECIALLY WHEN CHILDREN ARE PRESENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:**

**READ ALL INSTRUCTIONS BEFORE USING.**

## **DANGER-TO REDUCE THE RISK OF ELECTRIC SHOCK:**

- ALWAYS unplug the appliance from the electrical outlet immediately after using and before cleaning.

## **WARNING - TO REDUCE THE RISK OF BURNS, ELECTRIC SHOCK, FIRE OR INJURY TO PERSONS:**

**Caution:**  
To avoid injury and irreparable damage, always remain seated when using this footbath. NEVER stand on or in the unit.

- Close supervision is necessary when this appliance is used by, on or near children, invalids, or disabled persons.
- DO NOT operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged or dropped into water. Return the product to HoMedics Service Center for examination and repair.
- Keep cord away from heated surfaces.
- An appliance should NEVER be left unattended when plugged in. Unplug from outlet when not in use, before putting on or taking off parts, before filling product with water, and before emptying water from product.
- DO NOT operate under blanket or pillow.
- DO NOT carry this appliance by supply cord or use cord as a handle.
- NEVER operate the appliance with the air openings blocked. Keep the air openings free of lint, hair and the like.
- NEVER drop or insert any object into any opening.
- DO NOT use outdoors.
- DO NOT operate where aerosol (spray) products are being used or where oxygen is being administered.
- DO NOT immerse in water or any other liquid.
- To disconnect, turn all controls to the off position, then remove the plug from outlet.
- Use this appliance only for its intended use as described in this manual. DO NOT use attachments not recommended by HoMedics.
- DO NOT attempt to stand on or in your HoMedics footbath. Use only while seated.
- Connect this appliance to a properly grounded outlet only. See Grounding Instructions.
- This appliance is designed for personal, non-professional use only. This appliance should be used only for personal, non-professional uses.

# SAVE THESE INSTRUCTIONS

## SPECIAL WARNINGS

- DO NOT reach for an appliance that has fallen into water. Unplug it immediately.
- DO NOT use while bathing or showering. Use only in a dry area.
- DO NOT place or store appliance where it can fall or be pulled into a tub or sink. DO NOT place in or drop into water or other liquid.
- DO NOT attempt to plug or unplug unit while feet are in the water.
- Use appliance on a sturdy or level surface.
- If you have any concerns regarding your health, consult your doctor before using your HoMedics footbath.
- Consult your doctor before using in case of illness or medical condition, including but not limited to pacemaker use and pregnancy.
- We recommend using this unit for no longer than 30 minutes at a time. Extensive use could cause the product to overheat. Should this occur, discontinue use and allow the unit to cool before operating.
- If you experience pain in a muscle or joint for a prolonged period of time, discontinue use and consult your doctor. Persistent pain could be a symptom of a more serious condition.
- NEVER use any footbath on open wounds, discolored areas, or any area of the body that is swollen, burned, inflamed or where skin eruptions or sores are present.
- Use of this product should be pleasant and comfortable. Should pain or discomfort result, discontinue use and consult your physician.
- NEVER use while sleeping or drowsy.
- Always unplug the unit when filling or moving the unit.
- Ensure that your hands are dry when operating the controls or removing the plug.




Figure A




Figure B




Figure C




Figure D




Figure E

- This product should NEVER be used by any individual suffering from any ailments that would limit the user's capacity to operate the controls.
- This product should NEVER be used by any individual suffering from any ailments that would limit or altogether inhibit the user's capacity to feel or have any sensation in the body part that the product is being used for.

## Grounding Instructions

This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for the electric current to reduce the risk of electric shock. This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

### DANGER

**Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product - if it will not fit the outlet, you may temporarily use an adaptor (such as the one shown in Figure B) until you have a proper outlet (such as the one shown in Figure C) installed by a qualified electrician.**

This product is for use on a nominal 120-volt circuit, and has a grounding plug that looks like the plug illustrated in **Figure A**. A temporary adapter that looks like the adapter illustrated in **Figure B** may be used to connect this plug to a 2-pole receptacle as shown in **Figure D** if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet **Figure C** can be installed by a qualified electrician. The tab for grounding screw **Figure B** extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw. **See Figures D and E.**

## Bubble Bliss Elite Features

- Pedicure center with 3 attachments: Pumice Stone, Massaging Roller, and Brush.
- Invigorating bubbles to massage away aches and tension.
- Massaging rollers to roll away stress.
- Acupressure surface to stimulate and massage your feet.
- Three massage options: Massage with Heat, Bubbles with Heat, and Massage and Bubbles with Heat.

## Instructions for Use

1. Ensure that the unit is unplugged before filling with water. Fill with water to the max fill line - no higher.
2. Plug in and switch on.
3. Turn the function dial to indicate the massage of your choice.
  - 0 OFF
  - 1 Massage/Heat
  - 2 Massage/Bubbles/Heat
  - 3 Bubbles/Heat
4. Sit down and place your feet in the spa.
5. To use the Pedicure Center:
  - a. Select desired attachment:
    - Pumice Stone:** To smooth and soften dry skin on heels and soles of feet
    - Brush:** Use to clean and exfoliate skin
    - Massaging Roller:** Enjoy a relaxing massage from your heels to the balls of your feet
  - b. Simply place the attachment on the center post.
  - c. Push down with your foot to activate the attachment.
6. Enjoy a deep penetrating massage by sliding feet back and forth over the massage rollers in the bottom of the bath. Rollers are removable - pull the roller up and remove the entire roller holder.
7. To empty: First, unplug the unit. Tip the unit, allowing water to spill out along the drain spout. See Figure 1.

## Maintenance

### To Clean

Unplug the unit and allow it to cool before cleaning. Clean only with a soft, damp cloth and mild cleansing agent.

- After cleaning, wipe surfaces with a dry cloth.
- Never use strong abrasives, detergents or cleansing agents.
- Periodically straighten cord if it becomes twisted.

### To Store

Unplug the appliance from the outlet and allow to cool and dry.

- Store in its box or a clean, dry place.
- To avoid breakage, do not wrap the power cord around the unit.
- Do not hang the unit by the power cord.
- This appliance is designed for household use only.

Figure 1

