

QS-MYB-S315

HOMEDICS
soundspa lullaby
SOUNDS + PROJECTION



Hi, I hope you enjoy your
SoundSpa Lullaby!

1. projector lens
2. projector
3. project button
4. timer button
5. timer indicators
6. sound button
7. sound indicators
8. volume down
9. volume up
10. image disc
11. adapter
12. adapter jack



HOW TO USE:

Attach the adapter to the jack located on the back of the unit and then insert the cord into your standard household outlet.

LISTENING TO THE SOUNDS:

Press the sound button to turn the sounds on.

Press the sound button again to switch sounds and select the one you wish to listen to. The sound indicators will illuminate next to the sound icon when that sound is selected.

NOTE: When the unit is turned on, it will always default to the last sound used.

To adjust the volume, press the + button or - button to your desired level.

Press and hold the sound button for 2 seconds to turn the sound OFF.

USING THE PROJECTOR:

NOTE: The projector must be completely closed in order for it to function properly.

Turn on by pressing the project button . The projector will begin projecting at the high brightness setting.

Press the project button again to adjust the brightness to the low setting.

Press project button again to turn it off.

FRONT

QS-MYB-S315

USING THE AUTO TIMER:

When the sound and/or projector is on, press the timer button  once to set the 30-minute auto-off.

Press the timer button  again to set the 60-minute auto-off.

Timer indicators will illuminate according to which auto-off has been selected.

NOTE: Sounds and projection are independent functions. You can use one at a time or together.

NOTE: You can tilt the projector to move the location of the image on your ceiling.


TILTING THE PROJECTOR:

Press down on the top of either side of the projector to tilt it to your desired angle. The position of the projector images will be adjusted accordingly.

CHANGING THE PROJECTOR IMAGES:

Make sure projection is off and gently lift the projector out from the unit.

Locate the image disc on the bottom side of the projector.



Gently rotate the image disc until the desired image scene is over the lens. You will feel a click every time the new image scene is secured in place.




Image Disc



MORNING

AFTERNOON

NIGHT

NOTE: The image disc will only rotate a maximum of 2 positions (clicks) in a clockwise or counterclockwise rotation. If the image will not rotate in one direction, try rotating it in the opposite direction.


Line up the projector with the 3 grooves on the unit and place the projector back onto the unit.

CHANGING THE ORIENTATION OF PROJECTOR IMAGES:

Gently lift the projector out from the unit. Rotate the projector 120 degrees in either direction.

Line up the projector with the 3 grooves on the unit and place the projector back onto the unit.

The orientation of the projector images will be adjusted accordingly.



NEED HELP? CALL US: WE'LL GET TO YOU!
1-800-465-3342 (USA) | 1-888-228-7178 (CAN)
Learn more about our Bedtime Buddies at www.tommedsac.com/baby

QS-MYB315

BACK